

Low power and lightweight UAV sensors for methane and other petrochemical tracers

Mark A. Zondlo


Amir Khan, Lei Tao, David Miller, Kang Sun, Minghui Diao

**Dept. of Civil and Environmental Engineering
Princeton University**

ARPA-E Workshop:

**Ubiquitous methane leak detection through
novel sensors and sensing platforms**

29 March 2012, Washington, DC




Why laser-based sensors for methane on UAVs?

Performance

- high sensitivity
- fast response (< 1 Hz)
- high selectivity
- multispecies detection

Physical specifications

- low power (~ 1 W)
- low mass (\sim kg)
- compact size
- rugged



Only large UAVs (e.g. NASA Global Hawk, SIERRA) fly existing laser-based sensors

To fully utilize UAV capabilities, need low power, light weight, compact sensors for smaller, cheaper, easier-to-deploy UAVs and UAV fleets

Our key innovations:



***Vertical cavity surface emitting lasers
Open-path spectroscopy
Multiharmonic in-line stability system***



Vertical cavity surface emitting lasers (VCSELs)

Characteristics

- Inexpensive for mass production
- Very large tuning range
- Low power draw (15 mW)
- Near-infrared



Attributes for sensing

Inexpensive (\$5/laser in large qty.)
Multispecies detection at high S/N
Low power, lightweight sensors
Spectrally clean absorption lines



Above: VCSEL hygrometer for NSF Gulfstream-V aircraft, >700 flight hours, 0-15 km, polar regions to tropics (Zondlo et al., *J. Geophys. Res.*, 2010)

Open-path detection: advantages and challenges

Open-path detection: gas sampled at ambient conditions, no sample handling

Advantages

sampling minimized
no gas handling
fast response

gases


no inlet delay issues
no pumps (low power)
no phase re-partitioning

Challenges

spectroscopy over range of temp., pressure
need to know T, P in optical path
broad lineshapes, interferences from other

extreme, changing conditions
calibration

mirror/optics need to be relatively clean
(e.g. sea salt, dew/frost, bugs, mold)



Open-path detection is essential for low power applications/sensors
and in rapidly changing environments (high spatial resolution)



Multiharmonic in-line stability system

Problem: Open-path configurations difficult to calibrate, subject to drift


Solution: Continuous, in-line reference signal scanned; multiharmonic numerical fitting algorithm isolates reference signal from ambient

ambient
signal


in-line ref.

2.5 cm, 30 hPa 1% ethylene in N₂ w/ ambient NH₃


(a) Experimental 2f




(b) Experimental 6f



(c) Simulated 2f



(d) Simulated 6f




90mb
50mb
30mb
10mb
0

Reference signal unaffected by ambient absorption of interest in 6f detection

VCSEL sensors on UAV flight tests

- UAV test flight sensing, Nov. 2011 (UT-Dallas, David Lary)
- Successfully flew three sensors (CH_4 , CO_2 , H_2O) on T-REX Align 700E Helicopter
- 1.0-2.2 kg incl. batteries and all data acquisition/laser control electronics



Trace gas	Lower tropospheric range	Precision (1 Hz)	Mass/ Power
CO_2	350-450 ppmv	0.15 % (0.4 ppmv)	1.5 kg / 2 W
CH_4	1700-1900 ppbv	0.1 % (1.5 ppbv)	2.2 kg / 2 W
H_2O	50 – 50,000 ppmv	< 1 %	1 kg / 2 W

UAV VCSEL-based CH₄ sensor



Flew 135 m above ground, 20 m s⁻¹, rapid turns and accelerations



Quantum cascade lasers: simultaneous N_2O , CO , and C_2H_2

Characteristics

- probes fundamental ro-vi bands
- mid-infrared spectral region
- fully cryogenic-free



Attributes for sensing

- high sensitivity, simple designs
- most key atmospheric species
- long-term operation

N_2O precision at 1 Hz = 0.06 ppbv


CO precision at 1 Hz = 0.12 ppbv

Multiharmonic in-line maintains calibration of <0.4 ppbv N_2O over 24 hours

10 kg, 40 W, 35 x 18 x 15 cm

Tao et al., *Appl. Phys. B*, 2012b

Experimental $\text{N}_2\text{O}/\text{CO}/\text{C}_2\text{H}_2$ 2f & 4f Spectrum




- **CO distinguishes CH_4 from combustion, uncombusted leaks**
- **N_2O , C_2H_2 plume tracers when released at source (emissions)**



Methane UAV laser-based sensing

VCSEL-based UAV sensors

- first flight demonstration of UAV high-performance laser sensors for CH_4 , CO_2 , H_2O
~ 1-2 kg, 2 W for each system alone (unoptimized for mass, power at this point)
- simultaneous detection of $\text{CH}_4/\text{H}_2\text{O}$ or $\text{CO}_2/\text{H}_2\text{O}$
- high-performance (CH_4 : 1.5 ppbv prec., 1 Hz)
- multiharmonic, in-line system accounts for drift, greatly lowers maintenance
- future work: integrated systems, electronics to achieve 1 W, 1 kg for all three gases



QCL-based sensors

- simultaneous detection of CO , N_2O , and C_2H_2 for tracers to understand CH_4 emissions
- future work: sensors on circuit boards (fibers, waveguides) due to higher sensitivities

Low power, lightweight CH_4 (and other species) sensors excellent for quantifying, fingerprinting fugitive petrochemical emissions from UAVs



Laser-based sensors for methane emissions

Innovative detection schemes of newly-developed technologies:

1. Attributes of laser-based detection

Beer-Lambert law

Multi-harmonic in-line reference stability

Open-path (no pumps → low power)




2. Near infrared vertical cavity surface emitting lasers (VCSELs)

Methane, 1651 nm

Carbon dioxide, 2004 nm

Water vapor, 1854 nm



3. Quantum cascade lasers (QCLs)

Carbon monoxide/nitrous oxide/acetylene, 4.5 μm

Ammonia/ethylene, 9.1 μm

Merging of innovative optical devices and schemes with future airborne platforms!


- also of use in smartphone apps, remote locations, sensor networks, balloons, tethered balloons, kites





Ammonia in-line reference signal

Sun et al., Appl. Phys. B, 2012



- Reference signal stable to <4% over range factor three in ambient concentration
- Multiharmonic, numerical fitting algorithm isolates NH_3 , ref. signals



Laser absorption spectroscopy

$$\frac{I(\lambda)}{I_o(\lambda)} = \exp(-\alpha(\lambda))$$

where: $I(\lambda)$ is light intensity after absorption

$I_o(\lambda)$ is incident light intensity

$\alpha(\lambda)$ is absorbance

$$a(\lambda) = S(T) g(\lambda, T, P) N l$$



where: $S(T)$ is the linestrength

σ = cross section

$g(\lambda, T, P)$ is the normalized Voigt lineshape function

N is the absolute concentration

l is the pathlength



- we use combination of direct absorption and multi-harmonic wavelength modulation techniques with open-path configurations (no pumps)
- sensitive, selective, fast-response



NSF Gulfstream-V VCSEL hygrometer

Vertical Cavity Surface Emitting Laser, 1854 nm



(Zondlo et al., JGR, 2010)

~ 700 flight hours, routine on NSF G-V (since 2008)

1854 nm fiberized VCSEL, WMS and direct abs.

<u>Parameter</u>	<u>Specifications</u>
Dew point range	-110°C to +30°C
Sensitivity (1 Hz)	0.05 ppmv
Frequency	25 Hz
Accuracy	2-10%
Precision	≤ 1%
Power	8 W
Weight	6 kg
Size	25 cm × 16 cm × 5 cm
Operation	unattended
Design	open-path


29 cm



- VCSEL hygrometer is open-path
25 pass Herriott cell: 3.74 m path;
mirror radius=0.95 cm; 14.95 cm
mirror separation)
- 99.3% data coverage on global campaign
from the Arctic to tropics to Antarctic,
surface to the stratosphere



Multiharmonic in-line stability signal




Accuracy maintained <0.4 ppbv for 24 hours

- C_2H_2 Reference Cell: 50 Torr, 3 cm-long 100% C_2H_2
- C_2H_2 peak serves as continuous reference signal to account for system drift (which ultimately determines accuracy)
- higher harmonic (4f) detection isolates absorption lines at ambient pressures
- absolute calibration by NOAA GMD / WMO standards (0.07 ppbv accuracy)



Open-path Atmospheric Ammonia Sensing

Tao et al., Optics Express, 2012; Sun et al., Appl. Phys B, 2012



- 50 W power incl. laptop
- 300 pptv detection limit (1 Hz)
- field tested in desert, snow, rain, etc.

Challenges:

- Interference from other species, i.e. H_2O , CO_2
- Difficult to get the baseline of air-broadened absorption
- Have no control of temperature/pressure
- Calibration: need to enclose the open-path system

Solutions:

- ✓ Detecting ammonia line at $9.06\ \mu\text{m}$ – QC laser (more isolated)
- ✓ Wavelength modulation spectroscopy (WMS)
- ✓ T/P spectroscopic studies
- ✓ In-line ethylene calibration

